

RWY 22 - ABN 7W, AKUTI 7W, BODRU 7S, 7W, IRMAR 7T, 7W, MERLU 7W,

NORKA 7W, OKTET 7S, 7T, 7W, PERUS 7S, 7W, RUBAS 7W, STP 7W, VAREK 7W DEPARTURE

NICE, FRANCE



[USN] SHL-1744 (FR)

DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 22 L/R: At 300 FT, turn left to CGS R-115 (115°). Thence....

ABN 7W: Then turn left to CNM R-087 (087°). Turn left to intercept ABN 045° to ABN NDB.

AKUTI 7W: At CGS 8 DME, turn left to CNM R-087 (087°), then turn right to intercept NIZ VOR/DME R-115 (115°) to AKUTI.

NORKA 7W: At CGS 8 DME turn left to CNM R-087 (087°), then turn right to intercept NIZ VOR/DME R-127 (127°) to NORKA.

MERLU 7W: At CGS 7 DME, turn right to 220° then turn left to intercept NIZ VOR/DME R-185 (185°). At NIZ 34 DME, turn left to intercept STP R-100 (100°) to OMARD, then MERLU.

VAREK 7W: At CGS 7 DME, turn right to 220°, then turn left to intercept NIZ VOR/DME R-185 (185°). At NIZ 34 DME, turn left to intercept STP R-100 (100°) to OMARD, then turn right to NIZ R-161 (161°) to VAREK.

RUBAS 7W: At CGS 7 DME, turn right to intercept STP R-060 (240°) to STP 27 DME, then turn left to NIZ R-200 (200°) to RUBAS.

STP 7W: At CGS 7 DME, turn right to intercept STP R-060 (240°) to STP 27 DME, then turn left to NIZ VOR/DME R-200 (200°). At NIZ 34 DME, turn right to intercept STP R-100 (280°) to STP VOR/DME.

PERUS 7S: At CGS 7 DME, turn right to CNM VOR. At CNM VOR turn right to intercept CNM R-348 (348°) to AMIRO. At AMIRO, turn left to NIZ R-296 (296°) to PERUS.

PERUS 7W: At CGS 7 DME, turn right to NC NDB. At NC NDB turn right to intercept NC 323 to AMIRO. At AMIRO, turn left to follow NIZ R-296 (296°) to PERUS.

BODRU 7S: At CGS 7 DME, turn right to CNM VOR. At CNM VOR turn right to intercept CNM R-348 (348°) to AMIRO. At AMIRO, turn left to RNAV route 316° to BODRU.

BODRU 7W: At CGS 7 DME, turn right to NC NDB. At NC NDB turn right to intercept NC 323° to AMIRO. At AMIRO, turn left to RNAV route 316° to BODRU.

OKTET 7S: At CGS 7 DME, turn right to CNM VOR. At CNM VOR turn right to intercept CNM R-348 (348°) to AMIRO, then to OKTET.

OKTET 7W: At CGS 7 DME, turn right to NC NDB. At NC NDB turn right to intercept NC 323° to AMIRO. At AMIRO, turn right to CNM R-348 (348°) to OKTET.

IRMAR 7W: At CGS 7 DME, turn right to NC NDB. At NC NDB turn right to intercept NC 344° to BARSO. At BARSO follow RNAV route 355° to IRMAR.

TAKE-OFF RWY 22 L/R: At 300 FT, turn left to CGS R-100 (100°). Thence....

OKTET 7T: At CGS 14 DME, turn left to NIZ VOR/DME. At NIZ VOR/DME turn right to intercept NIZ R-326 (326°) to BARSO. At BARSO follow RNAV route 327° to OKTET.

IRMAR 7T: At CGS 14 DME, turn left to NIZ VOR/DME. Track to NIZ not above FL80. At NIZ VOR/DME turn right to intercept NIZ R-326 (326°) to BARSO. At BARSO follow RNAV route 355° to IRMAR.